



EN1176



S8

ASTM F1487
N/A

ASTM F1487



INSTALL 101

<p>WARNING Playground equipment installed over hard surfaces like asphalt, concrete, or packed aggregate may cause serious injury or death to children. Check the manufacturer's safety instructions to insert before allowing children to play.</p> <p>WARNING Children can become entangled in their clothes caught on slides and other playground equipment. Before allowing children to play remove belts, scarves, neckties, hooded sweat suits, neck scarves, or other items that may be an entanglement hazard.</p> <p>WARNING All playground equipment and rubber surfacing must be inspected for proper footing. Check for hot surfaces before allowing children to play. Children should wear appropriate shoes at all times.</p> <p>WARNING Playing high or moving on or under playground equipment can lead to serious injuries from falls, collisions, and head strikes. Do not use playground equipment if you are dizzy, tired, or under the influence of alcohol or drugs. The situation while playing will be impaired.</p>	<p>play smart® rules</p> <p>Do not play on broken or damaged equipment. Report it.</p> <p>Do not play without adequate safety training from your school or community.</p> <p>No talking, running or shouting should be done while on equipment.</p> <p>Do not play on top of surfaces and do not swing while playing.</p> <p>Do not play on or run on playground equipment and do not swing off of equipment.</p> <p>Watch your head! Do not run, slide, swing, climb, sit, or play on equipment when equipment is wet. Do not play on swings or on equipment if you are dizzy, tired, or under the influence of alcohol or drugs.</p> <p>Do not slide on metal, concrete, or asphalt.</p> <p>Do not slide with a child on your lap. Do not swing your child's legs. Do not swing your child's legs and do not swing with both feet.</p> <p>Do not swing down with your feet on the swing seat. Do not swing while swinging. Do not swing when</p>
--	---

HAGS®

FOR KIDS AGES
2-12
YEARS

ADULT SUPERVISION RECOMMENDED
www.hags.com


S9

CSA Z 614

N/A

N/A

CSA Z614



INSTALL 101

<p>WARNING</p> <p>Playground equipment must not be used as a structure, support or padding surface unless it is specifically designed for such use. Check for hot surfaces before allowing children to play.</p>	<p>WARNING</p> <p>Children are required to use only one surface caught on slides and other playground equipment. Before allowing children to play, verify that slides, ladders, rockers, twist, spin, and swings, and other equipment are properly installed and maintained.</p>	<p>play smart! rules</p> <p>Do not play on broken or damaged equipment. Report it.</p> <p>Do not play without adequate safety padding under and around equipment.</p> <p>No talking, running or shouting should be done while on equipment.</p> <p>Do not play on top of equipment and do not swing off of equipment.</p> <p>Do not play on or run on playground equipment and do not swing off of equipment.</p> <p>Watch your head! Do not run, climb, swing, rock, rotate, or spin equipment.</p> <p>Do not play on swings or on equipment that is not designed for such use.</p> <p>Do not play on trees or on equipment that is not designed for such use.</p> <p>Do not climb on trees, rocks, or other objects.</p> <p>Do not play on trees or on equipment that is not designed for such use.</p>
<p>WARNING</p> <p>All playground equipment and rubber surfacing must be inspected for proper fitting. Check for hot surfaces before allowing children to play. Children should wear appropriate shoes at all times.</p>	<p>WARNING</p> <p>Playing tag or running on or under playground equipment can lead to serious injury from falls, collisions, and head strikes. Do not use equipment for other than its intended purpose. The intention while playing will be penalized.</p>	<p>Adults - do not slide with a child on your lap. Do not rotate your child's legs.</p> <p>Before letting go of overhead bars, hand grips, and hand holds, your hands should be straight down with both feet.</p> <p>Do not swing down with your feet on the swing seat.</p> <p>Do not swing down with your feet on the swing seat.</p> <p>Do not swing down with your feet on the swing seat.</p>

HAGS





FOR KIDS AGES





18-12

MONTHS YEARS


ADULT SUPERVISION RECOMMENDED

www.hags.com







Install 101
448000
42008010
42800199
MASW26267
MASW26268
MASW26269
MASW26453





OM
Above Ground
 8061904



SF
Sunken Foundation
 8058991




BM/CC
Cast Loosefill
 8106338




MASW26268

42800199

x2



MASW26267



MASW26269

MASW26453