





UniPlay Gyttro



HAGS ANEBY, SWEDEN
+46(0)380-47300
www.hags.com

UniPlay Gyttro
MASW64978
1/4

LN LN 2018-04-17 1



15h



Varje vecka
Every week
Jede woche
Chaque semaine



Varje säsong
Every season
Jedes Jahr
Chaque saison





Step by Step UniPlay

REMEMBER!

Always handle carefully and do not use force when assembling. The product is made of plastic and metal. Do not use sharp tools to assemble. Do not use a hammer or screwdriver to assemble. Do not use a power drill to assemble. Do not use a power saw to assemble. Do not use a power sander to assemble. Do not use a power sander to assemble.

HAGS UniPlay Gyttro MASW64978 SE 1(3)





HAGS ANEBY, SWEDEN
+46(0)380-47300
www.hags.com

UniPlay Gytro
MASW64978
2/4

LN LN 2018-04-17 1

STEP 1



[m]



HAGS	ANEBY, SWEDEN +46(0)380-47300 www.hags.com
UniPlay Gytro MASW64978 3/4	
LN	LN 2018-04-17 1

STEP 2

[m]



HAGS ANEBY, SWEDEN
+46(0)380-47300
www.hags.com

UniPlay Gytro
MASW64978
4/4

LN LN 2018-04-17 1