HAGS

Slackline 3M







HAGS[®] [©] Playpower inc hags@hags.com www.hags.com **Slackline 3M** MA76701003



MA76701003

27/03/24







3







А





Check for hot surfaces before allowing childr to play. Children should wear appropriate shoes at all times.

WARNING Playing tag or running on or under playgroun equipment can lead to serious injuries from falls, collisions, and head strikes. do not rur on or under playground equipment. Pay attention while playing and be careful.

S8

✓ Watch your head! Do not run under bridges, decks, stairs, or other auipment. Aupment. Be careful when equipment is wet. Do not play on snowy or icy equipment Do not climb on roofs, railings, or osts, or on top of crawl through tub Slide sitting down feet first and a time. Do not slide up chutes or ubes. Adults – do not slide with a child o

/our lap. It can injure your child's legs ✓ Before letting go of overhead bars, hang down still, bend your knees a littl and drop straight down with both feet. Swing sitting down and do not jump out while swinging. Do not twist chain

HAGS[®] [©] Playpower inc hags@hags.com www.hags.com

3732 [12'-3"]

В





 Swing sitting down and do not jump out while swinging. Do not twist chain

Il playground equipment and rubber surfar may become hot enough to cause burns

Check for hot surfaces before allowing childr to play. Children should wear appropriate shoes at all times.

WARNING
Playing tag or running on or under playgroun
equipment can lead to serious injuries from
falls, collisions, and head strikes. do not rur
on or under playground equipment. Pay
attention while playing and be careful.

HAGS[®] [©] Playpower inc hags@hags.com www.hags.com